



Our customers come first.



## 2.08 - Democracy Suite<sup>®</sup> Adjudication System Operation Procedures

Version: 5.2-CO::119

February 15, 2017



TO LEARN MORE ABOUT OUR TECHNOLOGY, PEOPLE AND SERVICES  
VISIT [DOMINIONVOTING.COM](https://www.dominionvoting.com) TODAY



# NOTICE OF CONFIDENTIALITY AND NONDISCLOSURE

This document contains information that is protected as an unpublished work by Dominion Voting Systems (Dominion) under applicable copyright laws. The Recipient is to retain this document in confidence and is not permitted to copy, reproduce, or to incorporate the contents hereof into any other media other than as permitted in a written agreement with Dominion. The below statutory copyright notice shall not imply or be deemed publication of this product.

## PROPRIETARY NOTICE

The statements in this work, including, without limitation, directions, commentary, notes, and other elements contained herein, and their selection, expression, format, ordering and other attributes, constitute proprietary and confidential technical information and are protected under Canadian, United States and International copyright and other intellectual property laws. Title and all rights thereto, including, but not limited to all copyrights, trademarks and any trade secrets belong solely to Dominion. No distribution of any contained statements by a licensee or use by a distributee, whether as a product or a service, including without limitation, the right to copy, duplicate, reproduce, adapt, publish, quote, translate or incorporate into other formats, media, or derivative works of any kind, is permitted.

# RELEVANT DISCLAIMERS

The final list of items to be disclaimed in this release is to be confirmed. Please be advised that this document may make reference to the following Democracy Suite<sup>®</sup> functionalities:

- AIMS Data Translator
- Avalue tablets
- EMS Enterprise configuration
- Election Data Exchange Station (EDES)
- ImageCast<sup>®</sup> Evolution
- ImageCast<sup>®</sup> Evolution Dual Monitor functionality
- ImageCast<sup>®</sup> Listener
- ImageCast<sup>®</sup> Precinct
- ImageCast<sup>®</sup> Precinct Audio
- ImageCast<sup>®</sup> Precinct Ballot Marking Device (BMD)
- ImageCast<sup>®</sup> Precinct BMD Audio
- Rank Choice Voting (RCV)
- Recall Issues
- Mode 2 asymmetric cryptography
- Mode 3 asymmetric cryptography
- NYS General and Primary Ballot Template
- Modem and transmission functionality
- WinEDS Importer

These functionalities are not components of the current Democracy Suite<sup>®</sup> 5.2-CO certification campaign, and should be disregarded throughout the document.

# Revision History

Revision	Date	Author	Summary
119	2017-02-15	brian.fitzsimmons	Set majorrevision to 5.2-CO, set disclaimer to 5.2CO
117	2017-02-15	brian.fitzsimmons	Created 5.2CO branch from 5.2 branch
116	2017-02-08	brian.fitzsimmons	Propset on all .tex files
115	2017-02-06	brian.fitzsimmons	Created 5.2 branch from trunk
114	2017-02-06	brian.fitzsimmons	Revised naming of Adjudication client application and EMS Adjudication ...
107	2017-01-26	paul.chavezcasanova	Updated stale content for the 5.2 release.
106	2016-12-15	brian.fitzsimmons	Propset on all .tex files
105	2016-12-15	brian.fitzsimmons	Set disclaimer to 5.2
104	2016-12-14	brian.fitzsimmons	Set majorrevision to 5.2
103	2016-11-30	brian.fitzsimmons	Fixed broken link, added changes made to most recent 5.0 branch
102	2016-11-30	brian.fitzsimmons	Merged 5.1 branch changes into trunk
95	2016-08-30	dave.anderson	5.1 updates.
94	2016-08-09	brian.fitzsimmons	Updated trunk with changes made to 5.0 branch. Grammar edits
92	2016-04-25	jelena.bozic	Modified the doc for new installation document.
91	2016-04-23	tijana.todorovic	Updated document references.
88	2016-04-22	dave.anderson	Made updates for the separate tabulation store per election project. ...
87	2016-04-14	brian.fitzsimmons	Propset on all .tex files
86	2016-04-14	brian.fitzsimmons	Set majorrevision to 5.0. Set disclaimer to 5.0
85	2016-04-14	brian.fitzsimmons	Imported 4.21CO changes into trunk
79	2016-01-12	benjamin.rice	Added missing images.
78	2016-01-11	benjamin.rice	Minor change to install sequence for Adjudication client.
77	2016-01-11	benjamin.rice	Updated for Adjudication 4.21 release.
76	2015-10-01	brian.fitzsimmons	Updates from ADJ team. Added appendix from CO branch.
75	2015-09-30	matt.gawlik	Updates from ADJ team
52	2014-07-22	devan.vandenboomen	Updating major version number.
51	2014-07-17	geneice.mathews	Updated troubleshooting section and made minor updates to entire docum ...
50	2014-06-17	geneice.mathews	Corrected latex issue and updated images and text
49	2014-06-17	geneice.mathews	Updated images and text
48	2014-06-17	geneice.mathews	i/msgz
47	2014-05-28	devan.vandenboomen	Fixing fonts.
46	2014-05-28	geneice.mathews	Created a troubleshooting section
44	2014-05-05	geneice.mathews	Updated section 2.2.2
43	2014-04-29	geneice.mathews	Updated client section for clarity
38	2014-03-27	devan.vandenboomen	Correcting floating image.
37	2014-03-27	devan.vandenboomen	Level 4 technical edit and adding in Windows Server alternative steps. ...
36	2014-03-13	geneice.mathews	Updated a mistake in the requirements
35	2014-03-12	geneice.mathews	Updated 5.03 and corrected an extension
34	2014-03-11	geneice.mathews	Clarified section 4.1.2.2
33	2014-03-05	geneice.mathews	Added additional information on the drop folder share
32	2014-03-04	geneice.mathews	Updated section 4.1.3 to be more clear
31	2014-02-11	geneice.mathews	Added section to uninstall for more accuracy
30	2014-02-11	geneice.mathews	Updated pdf name of xca certificate
29	2014-02-11	geneice.mathews	updated sections based on QA feedback
28	2014-02-07	geneice.mathews	Updated all instructions once build submitted
27	2013-11-26	geneice.mathews	Updated Intro and beginning installation sections
25	2013-11-04	peter	Reverting from footnote on batched without outstack conditions.
24	2013-11-04	peter	Added footnote about unadjudicated batches having to be loaded from or ...
23	2013-11-01	geneice.mathews	Updated Operational section
22	2013-10-31	geneice.mathews	Updated Client Admin Mode section
21	2013-10-31	geneice.mathews	Updated Install and operational sections

# Contents

<b>Notice of Confidentiality and Nondisclosure</b>	<b>ii</b>
<b>Relevant Disclaimers</b>	<b>iii</b>
<b>Revision History</b>	<b>iv</b>
<b>List of Figures</b>	<b>1</b>
<b>1 Introduction</b>	<b>1</b>
<b>2 System Installation</b>	<b>2</b>
<b>3 Configuring Adjudication</b>	<b>3</b>
3.1 Adjudication Logging . . . . .	3
3.2 Locating EMS Adjudication Services . . . . .	3
<b>4 Operational Features</b>	<b>4</b>
<b>5 Operational Procedures</b>	<b>5</b>
<b>6 Operational Support</b>	<b>6</b>
<b>Appendices</b>	<b>7</b>
<b>A Troubleshooting</b>	<b>8</b>
A.1 Services Cannot Be Started Error . . . . .	8
A.1.1 Find Information about Installation Errors . . . . .	8
A.2 Authorization or Application Key Errors When Starting up the Client . . . . .	8
A.2.1 Verify Group Membership . . . . .	8
A.3 Other Errors When Starting up Adjudication client application . . . . .	9
A.3.1 Verify That the EMS Adjudication Services are Running . . . . .	9
A.3.2 Verify Remote Machines Can Reach the Adjudication Server . . . . .	10
A.3.3 Find Information about System Operation or Errors . . . . .	10
A.4 Client Starts but No Ballots or Batches Received . . . . .	10
A.4.1 Verify Communication over Message Queues . . . . .	11
A.4.2 Verify EMS Services Are Running . . . . .	11

# Chapter 1

## Introduction

EMS Adjudication (“Adjudication”) is a client and server application used to review and adjudicate vote results from ImageCast<sup>®</sup> tabulators. The application uses tabulator result files and scanned images to allow election administrators to make adjudications to ballots with auditing and reporting capabilities.

EMS Adjudication examines such voter exceptions as overvotes, undervotes, blank contests, blank ballots, write-in selections, and marginal marks.

The application works in two basic modes: election project setup and adjudication. Standard adjudication users only have the ability to adjudicate ballots; while adjudication administrator users have additional capabilities, such as viewing configuration settings and generating reports.

The application supports all ImageCast<sup>®</sup> tabulators and can be used in a multi-client environment. EMS Adjudication eliminates the need to physically rescan ballots, which can potentially damage the originals and cause chain-of-custody concerns.

## Chapter 2

# System Installation

For all instructions and details on installation and configuration of Adjudication, please see document *Democracy Suite<sup>®</sup> EMS System Installation and Configuration Procedure*.



# Chapter 3

## Configuring Adjudication

This chapter describes required procedures when using the application for ballot adjudication.

### 3.1 Adjudication Logging

In some cases the application informs the user to check the logs for more information. To access the logs:

1. Right-click the **Start** button in the lower left of the screen and click **Computer Management**.
2. Click **Event Viewer > Applications and Settings** and click **DVS Adjudication**.
3. To ensure all information listed is up to date click **Refresh** on the **Actions** pane to the right.
4. Select an entry to see its details on the bottom pane.

### 3.2 Locating EMS Adjudication Services

In some cases the application requests that the administrator check to ensure the EMS Adjudication Services are running. To find the services:

1. Right-click the **Start** button in the lower left of the screen and click **Computer Management**.
2. Click **Services and Applications > Services**.
3. In the **Services** pane, scroll to the services whose names begin with DVS.
4. The system currently has 10 services; make sure all are listed with a status of “Started”.

## Chapter 4

# Operational Features

Please refer to the following documents:

- *2.02 - Democracy Suite<sup>®</sup> System Overview*
- *Democracy Suite<sup>®</sup> Adjudication User Guide*
- *Democracy Suite<sup>®</sup> ImageCast<sup>®</sup> Central User Guide*

## Chapter 5

# Operational Procedures

Please refer to the following documents:

- *2.02 - Democracy Suite<sup>®</sup> System Overview*
- *Democracy Suite<sup>®</sup> Adjudication User Guide*
- *Democracy Suite<sup>®</sup> ImageCast<sup>®</sup> Central User Guide*

## Chapter 6

# Operational Support

Please refer to *2.09 - Democracy Suite<sup>®</sup> Adjudication System Maintenance Manual*.

# Appendices

# Appendix A

## Troubleshooting

This section reviews common troubleshooting issues that may occur while installing EMS Adjudication. In some cases there are multiple resolutions to review in order to fully resolve the issue.

### A.1 Services Cannot Be Started Error

If you receive an error from the EMS Adjudication Services installer that specifies that one of the services cannot be started please do the following:

#### A.1.1 Find Information about Installation Errors

These instructions can help pinpoint the cause of many installation issues from the EMS Adjudication Services installer or Adjudication client application installer.

1. Right-click the **Start** button in the lower left of the screen and click **Computer Management**.
2. While the installer is running, i.e, while it is still showing an error, check to see if the DVS Adjudication log is present in the **Event Viewer**, under **Applications and Services Logs**. If it is, check if there are any errors logged at the time the installation failed. To understand how to access event viewer please see section 3.1 Adjudication Logging.
3. In the **Event Viewer**, under **Windows Logs**, browse the Application and System logs for errors that occurred at the time the installation failed. These usually are from one of the following:
  - MSI Installer
  - One of the EMS Adjudication Services
  - Adjudication client application.

### A.2 Authorization or Application Key Errors When Starting up the Client

#### A.2.1 Verify Group Membership

1. Right-click the **Start** button in the lower left of the screen and select **Computer Management**.
2. Expand “Local Users and Groups”, under “System Tools”.
3. Select Groups; find the AdjudicationAdministrators and/or AdjudicationUsers groups on the center pane.
4. If you are on a remote client machine:
  - Double-click each group and verify that all the users of the machine that should be authorized are shown on the Members list (regular users on the AdjudicationUsers list, administrators on the AdjudicationAdministrators list).
  - If you make changes to the list of members, any affected users must log off and log back in to the machine for changes to apply. If you changed many users, it might be easier to restart the machine.

- Verify that any members of the groups are also members of the groups on the Adjudication server (see next step). Adding a user to the list on a remote machine is required but **does not** authorize the user; you must add the same user to a group on the server side.

5. If you are on the Adjudication server (or on a single-machine installation):

- Double-click each group and verify that all users, from this and any remote machines, that should be authorized are shown on the Members list (regular users on the AdjudicationUsers list, administrators on the AdjudicationAdministrators list).

**NOTE:** User account names must match the user names on remote machines, although case does not matter.

**NOTE:** The Adjudication system is primarily intended to work with local user accounts, as opposed to Windows domain accounts. If for some reason you need to authorize a domain user to use the system, you must create a local user on the server with the same name as the domain user, and also add it to the Adjudication groups in the same way any other user is added, otherwise authorization errors may occur.

- Verify that the service account (AdjSys) is present in the AdjudicationAdministrators group.
- If you change the service account's membership, then restart the EMS Adjudication Services by following the steps in section A.3.1 Verify That the EMS Adjudication Services are Running, except that at the end you should click Restart, instead of Start. Alternatively, you can restart the machine to force all services to restart.
- If you make changes to any other user membership, any affected users that are local to the machine must log off and log back in for changes to apply. If you changed many users, it might be easier to restart the machine.

## A.3 Other Errors When Starting up Adjudication client application

For errors that occur when starting up the Adjudication client application, please follow any troubleshooting instructions shown in the error message. If there are no instructions, find the error in the *2.03- Democracy Suite<sup>®</sup> EMS Functional Description* document and follow instructions there. Otherwise, please see below:

### A.3.1 Verify That the EMS Adjudication Services are Running

1. On the Adjudication server, open Computer Management. Right-click the **Start** button in the lower left of the screen and click **Computer Management**.
2. Select the Services node under "Services and Applications".
3. Scroll down until you find the group of EMS Adjudication Services. These are:
  - DVS Adjudicable Ballot Service
  - DVS Adjudication Data Service
  - DVS Ballot Completion Service
  - DVS Ballot Preparation Service
  - DVS Batch Completion Service
  - DVS Election Data Service
  - DVS Election File Manager
  - DVS Report Builder Service
  - DVS Report Service
  - DVS Statistics Service
4. Make sure all EMS Adjudication Services are running under the correct service account, AdjSys, by reviewing the **Log On As** column.
 

If any of the services are running under an incorrect account, change them as follows:

  - (a) Double-click the service name.
  - (b) Click the **Log On** tab and make sure **This account** is selected.
  - (c) Enter the correct service account (and password) and click **OK**.
  - (d) Right-click the service and click **Restart** (if this is not available, click **Start**).
5. Make sure all the EMS Adjudication Services show "Started" for the Status column. If any of them is not started, try to start them by right-clicking on them, and then selecting Start. If this fails, note the error, and contact technical support.

---

### A.3.2 Verify Remote Machines Can Reach the Adjudication Server

1. On a remote machine, open the Windows command prompt.
2. Type the command **ping server**, where server is the name or IP address of the Adjudication server. You should use the same name or IP you entered when installing the Adjudication client application. Example: ping ADJSERVER.
3. If you see replies from the server, e.g., lines starting with “Reply from”, then the server is reachable. In this case, look for other troubleshooting steps in this section that may help. If there are no replies, then there is a problem with the network configuration; in this case:
  - Check that network cables are properly connected.
  - Check network configuration issues using Windows Network and Sharing Center. Mainly, check that DNS/DHCP settings are correct, and that all computers are on the same network profile (e.g., Work or Public) with network discovery turned on. Please view *Democracy Suite<sup>®</sup> EMS System Installation and Configuration Procedure* for the DNS/DHCP settings.

### A.3.3 Find Information about System Operation or Errors

1. Right-click the **Start** button in the lower left of the screen and click **Computer Management**.
2. Expand System Tools and then Event Viewer.
3. Select the “DVS Adjudication” log under “Applications and Services Logs”.
4. To ensure all information listed is up to date, select the Refresh button in the Actions pane on the right.
5. On the center pane, entries logged by Adjudication components are displayed. The Source column identifies the exact component (e.g., one of the services, or the client).
6. If you are on the Adjudication server (or on a single-machine installation):
  - Errors from the “Election Data Service”, “Election File Manager” or “Ballot Preparer” usually indicate problems with the initial loading of batches or ballots from result files, including failures to obtain election information from the EMS system.
  - Errors from other services usually indicate communication or other processing problems once ballots have been adjudicated.
  - Note that some of the services retry operations automatically, so you may see the same error repeat every few seconds. Some errors are corrected automatically after retrying, at which point the error stops repeating, and no other action should be required.
7. If you are on a remote Adjudication machine, only entries from the “Adjudication client application” are displayed. Most processing problems occur on the server, so you should always check the server side logs as indicated in the previous step.

## A.4 Client Starts but No Ballots or Batches Received

If the Client has started, but no ballots or batches have been received, please ensure results have been loaded through RTR. Also note that it may take a few minutes for batches and ballots to appear.

If you still can't see ballots on the client, review the previous section A.3.3 Find Information about System Operation or Errors, or continue to the other instructions in this section.



---

## A.4.1 Verify Communication over Message Queues

If you are having problems on a specific client, follow these instructions on the machine where that client is open. If you are having problems with many clients, follow these instructions on the server first, and continue to remote client machines if needed.

1. Right-click the **Start** button in the lower left of the screen and click **Computer Management**.
2. Expand “Message Queuing”, under “Services and Applications”.
3. Select “Outgoing Queues”, right-click, and then Refresh.
4. The center pane should show established connections (if there are none, then start the Adjudication client application; if you are on the server, start a remote client). If the State column for any of the connections shows “Waiting to connect”:
  - (a) Sometimes restarting the MSMQ service resolves this. To do this:
    - i. Open the Services node (under “Services and Applications”).
    - ii. Right-click the “Message Queuing” service and then select Restart.

**NOTE:** If you are on the server, you will be asked if you want to restart the services that depend on the MSMQ service, select Yes to restart them.

- iii. Restart the client if it’s open. If you did this on the server, restart any open clients on remote machines.
- (b) This is usually a problem with network settings on the server or clients.
    - Check that computers on the network can reach each other using IP addresses. See section A.3.2 Verify Remote Machines Can Reach the Adjudication Server.
    - Use Windows Network and Sharing Center to check DNS/DHCP settings, and ensure that all computers are on the same network profile (e.g., Work or Public) with network discovery turned on. Please see *Democracy Suite<sup>®</sup> EMS System Installation and Configuration Procedure* for the correct DNS/DHCP settings.

## A.4.2 Verify EMS Services Are Running

1. Open a Web browser on the server machine.
2. Enter the URL **http://localhost/EMSApplicationServer/CvrService.svc** into the address bar.
3. Verify that the **CvrService Service** screen appears.

